


THE ENDURING, ESTHETIC VENEER CEMENT



More than 20 years of clinical performance;
thixotropic nature for favorable handling

Technique Guide


Calibra® Veneer Esthetic Resin Cement



1 Apply Calibra® Try-In Paste

Gently seat onto preparation. Clean excess with a cotton pellet and/or blunt explorer. Shades may be blended to achieve optimum esthetics.

Important Technique Tip: Try-in paste is a guide for cement shade range selection only. *NOTE: The try-in paste will not polymerize, thus offers unlimited work time.*




2 Clean and dry

Once fit and esthetics are verified, thoroughly clean all internal surfaces of the veneer with water spray and dry.



3 Pre-treatment¹


Apply 5% hydrofluoric acid (follow Directions for Use) to intaglio only. Dry thoroughly and apply Calibra Silane Coupling Agent and leave undisturbed for 60 seconds. Repeat application, if layer has dried up. Evaporate solvent with a strong air stream.



4 Apply tooth conditioner gel²

Apply tooth conditioner gel to available enamel (and dentin, if desired). Rinse and blot dry to keep moist. Do not rub.

(in Europe: DeTrey Conditioner 36%)



5 Apply adhesive to tooth

Apply Prime&Bond® elect² adhesive and leave undisturbed for 20 seconds.




6 Air dry

Gently air dry for 5 seconds.

1. Follow restoration material's instructions for use
2. Please consult instructions for use

Technique Guide


Calibra® Veneer Esthetic Resin Cement



7 **Light cure**
Light cure adhesive for 10 seconds.




8 **Apply Calibra Veneer cement**
Dispense the desired Calibra Veneer cement shade directly onto the veneer. Protect cement from exposure to light.




9 **Seat restoration**
If possible, place mylar strips between preparation and adjacent teeth. Seat restoration slowly.




10 **Clean up excess**
Tack the veneer in place by briefly light curing the gingival portion only for no more than 10 seconds.



11 **Remove excess cement**
Remove mylar strip and lift off excess cement around margins.



12 **Light cure**
Light cure all marginal areas for 20 seconds from each direction - buccal, lingual and interproximal aspects.



13 **Finish & polish**
Removal of resin flash is best accomplished with the Enhance® Finishing System and polish using Enhance® PoGo® Polishing System (see complete instructions for use).

Tips on Material Pre-Treatment

Material	Pre-Treatment*
Composite	Sandblast (except for composite post surface)
Glass Ceramic/ High Strength Glass Ceramic	Etch with hydrofluoric acid, silanize with Calibra® Silane Coupling Agent
Zirconia/Metal	Sandblast (except for zirconia post surface)

**Some manufacturers may require additional primers. Please consult instructions for use.*